

## HEAVY DUTY INSPECTION MIRROR ASSEMBLY GUIDE

1. Assemble as shown in diagram below.
2. Tension nyloc nut as necessary (do not over tighten, as damage may occur to the handle).

